

AF05/OF05 Range

High voltage air and oil fume purification power supply



Specification Summary

The AF05/OF05 is a highly compact and efficient, mains powered high voltage power supply. The primary application is for air or oil fume purification. However, it is also suitable for capacitor charging and other general purpose application.

The AF05/OF05 has a precise, stable and adjustable output voltage and output current. It is safe and reliable, with a high tolerance to the noise generated by electrical discharges.

Input Specification

The input voltage range is 200VAC to 240VAC
Less than 5A
150W, 300W, 450W and 1000W
10kV, 15kV, 20kV adjustable
Less than 1%
Less than 1%
300ppm/°C maximum

Short circuit	In the event of an output short circuit,
	the output current will remain at the
protection	set value.


Over-current protection	In the event of an output over-current, the output current will remain at the set value.	
Spark protection	When the power supply experiences a spark on load, the output will be switched off momentarily. After which, it will be restored automatically.	

Control interface

Local control mode:

The output voltage and current can be adjusted by the two potentiometers next to the 9 way D type connector. By winding both potentiometers clockwise increases the output.

Details about the 9 way D type female connector in default settings:



Genvolt Ltd, New Road, Highley, Bridgnorth, Shropshire, WV16 6NN, UK. T: +44(0)17460 862555 F: +44(0)17460 862666 E: info@genvolt.co.uk W: www.genvolt.co.uk



Genvolt design, develop and manufacture

a wide range of high voltage power supply systems

1	DGND	Digital ground
2	FAULTY/FUNCTIONAL	OC output; OPEN=SPARK or FAULTY or STOP WORKING, CLOSE= FUNCTIONAL
3	VDEM	To be defined
4	GND	Analogue ground
5	VFBK	Voltage feedback 0 to 5V=0 to maximum voltage
6	L/R MODE	To be defined
7	HV INHIBIT	0V or FLOATING=ON, 12V=OFF
8	IDEM	To be defined
9	IFBK	0 to 5V = 0 to maximum current

Remote control mode:

Remote control is also available for AF05. For further information please contact the factory.

Environmental Requirements

Ambient temperature	-10°C to 50°C
Storage temperature	-20°C to 80°C
Relative humidity	Less than 90%

Mechanical Specifications


Power range	150W	300W	450W
Width	150mm	150mm	150mm
Height	95mm	95mm	95mm
Depth	220mm	220mm	220mm
Weight	1kg	1.5kg	1.6kg

Reliability and Quality Control


Each power supply has been tested with no load, short circuit load and sparking. They have also been soak tested for no less than 48 hours at full load.

Safety

- This power supply contains hazardous voltages and stored energy. Contact with the output may result in fatal injury. It should only be used and maintained by trained personnel.
- The area where the power supply is to be used should be kept clean and dry.
- Keep a safe distance from the output connector and any items connected to it.
- Ensure that a secure connection is made between the Earth side of the load and the green and yellow Earth lead.



Top View



Front View

For requirements other than those specified, please do not hesitate to contact the factory.

Genvolt Ltd, New Road, Highley, Bridgnorth, Shropshire, WV16 6NN, UK. T: +44(0)17460 862555 F: +44(0)17460 862666 E: info@genvolt.co.uk W: www.genvolt.co.uk